





Fake Worms DIY



Duration: 20 min



Difficulty: **Easy**



Cost: \$0 to \$10

Use calcium chloride and sodium alginate to make fake worms!

Material List

- Teaspoons of sodium alginate
- Bowl with 1 cup of water
- Plastic bottle with 1 cup of water
- Food coloring
- Stirring utensil
- Pair of safety glasses
- Pair of gloves

Instructions

- Tablespoons calcium chloride Add 2 tablespoons of calcium chloride to the bowl of water and mix it.
 - Into the bottle, add a few drops of food coloring and a half teaspoon of sodium alginate.
 - Cap the bottle immediately and shake it for 30 seconds. It can take some time to dissolve.
 - Pour the liquid in the bottle, into the bowl (try to make one continuous stream of liquid).
 - Wait 10 seconds and pull out the new substance.

How It Works

The chemical reaction between two natural resources (calcium chloride and sodium alginate) forms a synthetic material. Sodium alginate comes from algae and calcium chloride comes from rocks. The gel-like substance is formed because the sodium alginate reacts with the calcium chloride, to form calcium alginate. Fun fact: this synthetic material is used by doctors to help wounds heal faster.